



## OSSI-010-035 Sonic Wave Sensor XB Quick Start Guide

---

This guide will assist the user to obtain data from the Sonic Wave Sensor XB in the quickest time possible. The user is advised to read the user manual and Specification sheet in its entirety before actual deployment.

1. After unpacking the unit, check to see there is a USB Adapter, Sonic Wave Sensor XB and two C cell Batteries.
2. Install the XBee to USB adapter on your computer, with an internet connection. The adapter has been pre-configured to operate with your Sonic Wave Sensor XB.
3. Download and Install the Staff Products Interface Software at [www.oceansensorsystems.com](http://www.oceansensorsystems.com).
4. Run the Staff Products Interface Software and select Wave Staff XB & Sonic Wave Sensor XB and the com port (USB to Serial Port).
5. Unscrew the top of the Sonic Wave Sensor XB (The part with the label) and add two C cell batteries. (Positive end up) Screw the top back on firmly but not too tight.
6. On the Staff Products Interface Software set the Broadcast Power switch to the on position.
7. The unit will now power-up in a few minutes and start sending sampled data to the Interface Software program.