



## OSSI-010-025 Wave Staff XB Quick Start Guide

---

This guide will assist the user to obtain data from the wave Staff XB in the quickest time possible. The user is advised to read the user manual in its entirety before actual deployment.

1. After unpacking the unit, check to see there is a USB Adapter, Wave Staff XB and C cell Batteries.
2. Install the XBee to USB adapter on your computer, with an internet connection. The adapter has been pre-configured to operate with your Wave Staff XB.
3. Download and Install the Staff Products Interface Software at [www.oceansensorsystems.com](http://www.oceansensorsystems.com).
4. Run the Staff Products Interface Software and select Wave Staff XB and the com port (USB to Serial Port).
5. Unscrew the top of the Wave Staff XB (The part with the label) and add two C cell batteries. (Positive end up) Screw the top back on firmly but not too tight.
6. On the Staff Products Interface Software set the Broadcast Power switch to the on position.
7. The unit will now power-up in a few minutes and start sending sampled data to the Interface Software program.